

# VRK Series System Operation Guide



### Call buttons

Press the appropriate button and wait for a reply. A reassurance tone will be heard.

### Trades button (optional)

For Postman and deliveries. Press and hold during the allocated time to unlock the door.

### Microphone

### Speaker

Intelligent Security & Fire Ltd

# 801 Audio Telephone



## Key button

This button opens the calling entrance

Intelligent Security & Fire Ltd