

USER INSTRUCTION

Art.3011 Telephone



Three position volume control:

Use this to adjust the incoming call volume.

● **HIGH**
 ● **MEDIUM**
 ● **LOW**

Door release button:

Press this at any time to release the door (With or without the handset lifted).

IMPORTANT NOTE: The incoming call tone comes out of the telephone ear piece.

Do not hold the hook switch down while holding the telephone to your ear.


STEP 1

An incoming call will be signalled by an audible tone from the handset

STEP 2

Pick up the handset and speak with the caller

STEP 3

To open the door press the  button
 To end the call simply hang up